

18 JUN 20

VISUAL


BRIZE NORTON

Elev 287	Var 0°	TA 3000 ①	TRL ATC	18 JUN 20	V1
BRIZE RADAR 278.35 124.275	APPROACH 231.95 127.25	TOWER 269.175 123.725	GROUND 341.2 121.725	ATIS ② 284.975 126.5	

EGVN/BZZ ENGLAND

Changes: Var

No1 AIDU Last Amended 06 MAR 20



- ① TA 6000 inside DTY CTA.
- ② 126.5 VHF freq subject to availability.
- ③ Fairford MATZ activated by NOTAM.
- 4. Prior to entering CTR, request permission from BRIZE ZONE 119.0 when 15nm or 5 minutes flying time (whichever earlier) from boundary.
- 5. Light aircraft and rotary traffic arriving/departing RAF Brize Norton under VFR will normally be required to enter or leave the Brize Norton CTR via the Burford or Faringdon Visual Reporting Points. Arriving/departing traffic is to proceed not above 1300 QNH between RAF Brize Norton and the Visual Reporting Points or as directed by TWR/Zone.

BRIZE NORTON
MIPS

VISUAL

© UK MOD Crown Copyright 2020. No1 AIDU is not responsible for, and claims no right to, the content or accuracy of 3rd party documents/information.